


Black & Decker®


WALLMATE FB1




1




2




4




5




6




8











9



10





- (a) Accurate and secure fixing of the unit to the wall is essential for successful use (See illustration 10). Check that the vice brackets are parallel and adjust wall brackets by the slots provided to achieve this.
- (b) Cut the wall plug provided into six equal sections. The six drilled holes in the wall must be 6.5mm in diameter (See illustration 11).
- (c) Many clamping permutations can be achieved by the positioning of the rear jaw (B) in the key hole slots. To provide extra clamping angularity rear jaw (B) can be placed one key hole out of line. The vice pegs will allow even greater clamping capacity and versatility.
- (d) Shelves can be obtained separately from Black & Decker Service Centres which give a large storage area and the Wallmate folds flat against them (See overleaf).
- (e) **Attachments** WM110 Workmate Universal Extender Arms which significantly increases the holding capacity fits this unit.

Caution

Do not use Bench Top (C) as a clamping edge. The two Vice Jaws (A) and (B) are used to grip the workpiece and are capable of exerting tremendous pressure and leverage. It is important, therefore, not to apply excess force to the Vice Handles otherwise damage may be caused to the workpiece, especially if it soft or delicate.

Caution

Although the Wallmate can be used to provide a secure and safe mount for power tools and attachments it is important always to disconnect the power tool from the mains supply when making adjustments.

Caution


Do not stand on top of this unit.

Caution

Check all moving parts, fixings, pivots etc. for wear, damage or looseness. Repair as necessary before use and lubricate where required on a regular basis.

Caution

Make sure that the Front Jaw (A) is lowered into the catch to provide safe wall storage (See illustration 14).



AFTER SALES SERVICE FOR YOUR BLACK & DECKER PRODUCT

Black & Decker offers you a nationwide after sales service through our company operated Black & Decker Service Centres. Full details of these are given below.

It is our aim to offer you excellent service, fast repairs, extensive parts availability and full accessory support.

Visit a Black & Decker Service Centre and **PUT US TO THE TEST.**

GUARANTEE

If your Black & Decker product becomes defective due to faulty materials or workmanship within 12 months from the date of purchase, we guarantee to replace all defective parts free of charge or at our discretion replace the unit free of charge provided that:—

1. The product is returned to a Black & Decker Service Centre with evidence of purchase date.
2. The product has been purchased for the user and not used for hire purposes.
3. The product has not been misused or carelessly handled.
4. Repairs have not been attempted by persons other than our Service Staff or overseas by our own or distributors' staff.

The Guarantee is offered as an extra benefit and is additional to your statutory rights.

WHAT TO DO IF YOUR BLACK & DECKER PRODUCT NEEDS REPAIR

If your Black & Decker product should need repair the quickest and simplest way is to take or send it to a Black & Decker Service Centre, addresses given below, providing proof of purchase if a guarantee repair is required.

If you have any difficulty please contact our Service and Information Centre 062882 2233 who will give you every assistance.

OUR REPAIR POLICY

Our policy on consumer and garden product repairs is to dismantle the unit and replace all faulty or worn parts. The unit is then subjected to electrical and mechanical tests. This procedure enables us to offer a one year unconditional guarantee on all repairs. We do not carry out partial repairs, nor is it our policy to carry out preventive maintenance (servicing) other than as part of our comprehensive repair. In some instances due to the age, type or mechanical condition of a unit we undertake to replace your unit with a new or reconditioned unit at a favourable price, instead of a repair. In such cases we:—

- a) Offer the same 1 year guarantee.
- b) Will, if your unit is not brought into a Black & Decker Service Centre (when the exchange option can be explained to you personally), return your old unit to you with the new exchange tool and a post paid label for its return free of charge if you do not wish to accept the exchange.

We will normally be able to advise you if your unit falls into this category if you contact us at one of the addresses below.

OUR AFTER SALES SERVICE POLICY

It is our aim that all Black & Decker customers should be wholly satisfied with our products and our after sales service. If you have any cause for dissatisfaction, please contact our Service & Information Centre giving us details. You will receive prompt and sympathetic attention.

Black & Decker SERVICE
04 SERVICE FOR THE 60s

BLACK & DECKER SERVICE CENTRES:

Belfast, Glenwell Road, Glengormley, Newton Abbey, Co. Antrim. Tel: 02313 41071
Birmingham, Long Acre, Birmingham 7. Tel: 021-327 3411
Bradford, 5 John Street, Bradford. Tel: 0274 29332
Bristol, 25/27 Stokes Croft, Bristol. Tel: 0272 45018
Cardiff, 175 Cowbridge Rd. East, Canton, Cardiff. Tel: 0222 21547
Edinburgh, 11 Queens Ferry Street, Edinburgh. Tel: 031-226 7479
Glasgow, 105/107 Gintanar Road, Balmore Industrial Estate, Glasgow G22. Tel: 041-336 8697
Hull, 91/92 Prospect Street, Hull. Tel: 0482 223587
Leeds, 1 Lockwood Close, Middleton Grove, Leeds. Tel: 0532 714019
Leicester, 42 Abbey Street, Leicester. Tel: 0533 27087
Liverpool, 706 Prescott Road, Old Swan, Liverpool. Tel: 051-220 3636

London-North, 623 Holloway Road, London N19. Tel: 01-272 8246
London-South, 30 The High Parade, Streatham High Road, London SW16. Tel: 01-677 2164
London-East, 1 Brooks Parade, Green Lane, Goodmayes, Essex. Tel: 01-590 5859
London-West, Bath Road, Harmondsworth, Middlesex. Tel: 01-759 2411
Luton, 45 New Bedford Road, Luton. Tel: 0582 26565
Manchester, Knott Mill, Manchester. Tel: 061-834 8865
Maidenhead, Cannon Lane, Maidenhead, Berks. Tel: 0628-82 2233
North Harrow, 9 Broadway Parade, Pinner Road, North Harrow. Tel: 01-427 4171
Norwich, 28 Prince of Wales Road, Norwich. Tel: 0603 27600
Nottingham, 361 Carlton Hill, Nottingham. Tel: 0602 24018
Plymouth, 65/67 Exeter Street, Plymouth. Tel: 0752 27064

Sheffield, 15 London Road, Sheffield. Tel: 0742 760743
Southampton, 117a East Street, Southampton. Tel: 0703 23915
Spennymoor, Green Lane, Spennymoor, Co. Durham. Tel: 0388 815815
Tyneside, Bergen Close, Tyne Tunnel Trading Estate, Percy Main, North Shields. Tel: 0632-576117
Eire
Dublin 10, Killeen Road, Kylemore Industrial Estate, Ballyfermont, Dublin 10. Tel: Dublin 266623
Dublin 2, 205 Pearse Street, Dublin 2. Tel: Dublin 774020
Cork, 28 Glanmire House, Glanmire Road, Cork. Tel: Cork 507140
Galway, Feletric Ltd., Unit 3, Galway Industrial Estate, Galway. Tel: Galway 64777

If you have any queries or problems about After-Sales Service, contact our Central Service and Information Centre at Maidenhead on Littlewick Green 2233 (0628-82) or Telex 847801.

Black & Decker

Cannon Lane, Maidenhead, Berks. Tel: Littlewick Green 2130
STD. 0628-82 2130